

Technical data sheet Safety laser scanner

Part no.: 53800310

RSL420P-L/CU400P-AIDA-OF



Contents

- Technical data
- Dimensioned drawings
- Electrical connection
- Operation and display
- Notes
- Accessories











Technical data



Basic data

Series	RSL 400
Application	Mobile danger zone guarding
	Mobile side guarding
	Stationary access guarding
	Stationary danger zone guarding

Functions

Functions	PROFIsafe
	Resolution, selectable

Characteristic parameters

Туре	3, IEC/EN 61496
SIL	2, IEC 61508
SILCL	2, IEC/EN 62061
Performance Level (PL)	d, EN ISO 13849-1
PFH _D	9E-08 per hour
Mission time T _M	20 years, EN ISO 13849-1
Category	3. EN ISO 13849

Protective field data

Scanning angle	270 °
Minimum adjustable range	50 mm
Number of field pairs, reversible	10
Number of protective functions	1 Piece(s)
Number of independent sensor configurations	1
Diffuse reflection, min.	1.8 %
Operating range	0 6.25 m

Warning field data

Number of field pairs	10
Operating range	0 20 m
Object size	150 mm x 150 mm
Diffuse reflection, min.	1.8 %

Optical data

Light source	Laser, Infrared
Laser light wavelength	905 nm
Laser class	1, IEC/EN 60825-1:2007
Transmitted-signal shape	Pulsed
Repetition frequency	90 kHz

Measurement data

Distance resolution	1 mm
Detection range	0 50 m
Diffuse reflection	20 %
Angular resolution	0.1 °
Angular resolution	0.1

Electrical data

Protective circuit	Overvoltage protection

Performance data

	Supply voltage U _B	24 V, DC, -30 20 %
	Current consumption (without load), max.	1,000 mA, (use power supply unit with 3 A) $$
	Power consumption, max.	24 W, For 24 V, plus output load

Interface

Туре		PROFINET
	Profinet	
	Function	Process
	PROFINET device	Device acc. to Spec V2.3.4
	GSDML	GSDML acc. to Spec V2.3.2
	Profile	PROFINET/PROFIsafe
	Conformance class	С
	Network load class	III
	Security level	1
	Switch functionality	IRT-ready 2-port switch acc. to IEEE 802, integrated in connection unit
	Port properties	Auto-Crossover
		Auto-Negotiation
		Auto-Polarity
	I&M	0 - 4
	Supported topologies	MRP client
		SNMP
	Safety-related switching signals	1 Piece(s)

Service interface

Co. Vice interitors		
Type		Bluetooth, USB
ВІ	uetooth	
Fu	nction	Configuration/parametering
Fre	equency band	2,400 2,483.5 MHz
Ra	diated transmitting power	Max. 4.5 dBm (2.82 mW), class 2
US	SB	
Fu	nction	Configuration/parametering
Co	onnection	USB 2.0 mini-B, socket
Tra	ansmission speed, max.	12 Mbit/s
Ca	ble length	≤ 5m Longer cable lengths are possible using active cables.

Connection

Connection		
Number of connections	4 Piece(s)	
Connection 1		
Function	Voltage supply	
Type of connection	PROFINET push-pull 24V	
Connection 2		
Function	PROFINET/PROFIsafe communication, input	
Type of connection	PROFINET SCRJ push-pull ISO/ IEC 61754-24-2	
Connection 3		
Function	PROFINET/PROFIsafe communication, output	
Type of connection	PROFINET SCRJ push-pull ISO/ IEC 61754-24-2	
Connection 4		
Function	Voltage supply	
Type of connection	PROFINET push-pull 24V	

Technical data



Mechanical data

Dimension (W x H x L)	140.2 mm x 200 mm x 142 mm
Housing material	Metal
	Plastic
Metal housing	Diecast zinc
Lens cover material	Plastic/PC
Net weight	4,500 g
Housing color	Yellow, RAL 1021
Type of fastening	Mounting plate
	Through-hole mounting
	Via optional mounting device

Operation and display

Type of display	Alphanumerical display
	LED indicator
Number of LEDs	10 Piece(s)
Type of configuration	Software Sensor Studio
Operational controls	Software Sensor Studio

Environmental data

Ambient temperature, operation	0 50 °C
Ambient temperature, storage	-20 60 °C
Relative humidity (non-condensing)	15 95 %

Certifications

Degree of protection	IP 65
Protection class	III, EN 61140
Certifications	TÜV Süd
Test procedure for EMC in accordance	DIN 40839-1/3
with standard	EN 61496-1
Test procedure for oscillation in accordance with standard	EN 60068-2-6
Test procedure for continuous shock in accordance with standard	IEC 60068-2-29
US patents	US 10,304,307B
	US 7,656,917 B
	US 7,696,468 B
	US 8,520,221 B

Classification

Customs tariff number	85365019	
eCl@ss 5.1.4	27272705	
eCl@ss 8.0	27272705	
eCl@ss 9.0	27272705	
eCl@ss 10.0	27272705	
eCl@ss 11.0	27272705	
ETIM 5.0	EC002550	
ETIM 6.0	EC002550	
ETIM 7.0	EC002550	


3/8

Dimensioned drawings



All dimensions in millimeters

Dimensions safety laser scanner with connection unit





1 Scan level

Dimensioned drawings



Mounting dimensions safety laser scanner with connection unit





¹ Reference point for distance measurement and protective field radius

Electrical connection

Connection 1	XD1
Function	Voltage supply
Type of connection	PROFINET push-pull 24V
No. of pins	5 -pin

Electrical connection



Pin	Pin assignment
1	+24V
2	0 V
3	+24V
4	0 V
5	GND



Connection 2	XF1	
Function	PROFINET/PROFIsafe communication, input	
Type of connection	PROFINET SCRJ push-pull ISO/IEC 61754-24-2	
Connection 3	XF2	
Function	PROFINET/PROFIsafe communication, output	
Type of connection	PROFINET SCRJ push-pull ISO/IEC 61754-24-2	
Connection 4	XD2	
Function	Voltage supply	
Type of connection	PROFINET push-pull 24V	
No. of pins	5 -pin	

Pin	Pin assignment
1	+24V
2	0 V
3	+24V
4	0 V
5	GND



Operation and display

LE	D	Display	Meaning
1		Off	Device switched off
		Red, continuous light	OSSD off
		Red, flashing	Error
		Green, continuous light	OSSD on
2	-	Off	RES deactivated or RES activated and released
		Yellow, flashing	Protective field occupied
		Yellow, continuous light	RES activated and blocked but ready to be unlocked - protective field free and linked sensor is enabled if applicable
3	-	Off	Free warning field
		Blue, continuous light	Warning field interrupted
4	-	Off	Four field mode: warning field 3 free
		Blue, continuous light	Four field mode: warning field 3 interrupted
5	-	Yellow, flashing	Four field mode: warning field 2 interrupted
6	-	Off	No function
7	PWR	Off	Device switched off
		Red, continuous light	Error during self test or internal communication problems
		Green, flashing	PROFINET wave function active
		Green, continuous light	Device switched on, supply voltage applied, no internal error
8	PS	Off	PROFIsafe communication not initialized or switched off
		Green, flashing	Device in passive state or PROFINET wave function active
		Green, continuous light	Device on PROFIsafe active
		Red, flashing	PROFIsafe configuration failed
		Red, continuous light	PROFIsafe communication error
9	NET	Off	PROFINET communication not initialized or inactive
		Green, flashing	PROFINET bus initialization or PROFINET wave function active





LE	D	Display	Meaning
9	NET	Green, continuous light	PROFINET active, data exchange with IO controller active
		Orange, flashing	Ethernet topology error
		Red, flashing	Ethernet configuration failed, no data exchange or exchange of invalid data
		Red, continuous light	Bus error, no communication
10	LNK/ACT1	Off	No Ethernet link present
		Green, continuous light	Ethernet link active, no current data transmission
		Green/orange, flashing	Ethernet link active, current data transmission
11	LNK/ACT2	Off	No Ethernet link present
		Green, continuous light	Ethernet link active, no current data transmission
		Green/orange, flashing	Ethernet link active, current data transmission

Notes



Observe intended use!



- \$ The product may only be put into operation by competent persons.
- \$ Only use the product in accordance with its intended use.



WARNING! INVISIBLE LASER RADIATION - CLASS 1 LASER PRODUCT



The device satisfies the requirements of IEC 60825-1:2014 (EN 60825-1:2014) safety regulations for a product of laser class 1 as well as the U.S. 21 CFR 1040.10 regulations with deviations corresponding to "Laser Notice No. 56" from May 8, 2019.

- ♥ Observe the applicable statutory and local laser protection regulations.
- The device must not be tampered with and must not be changed in any way. There are no user-serviceable parts inside the device.
 Repairs must only be performed by Leuze electronic GmbH + Co. KG.

Accessories

Mounting technology - Mounting brackets

	Part no.	Designation	Article	Description
	53800134	BT840M	Mounting bracket	Application: Mounting on chamfered 90° corner Dimensions: 84.9 mm x 72 mm x 205.2 mm Color: Yellow, RAL 1021 Type of fastening, at system: Through-hole mounting Type of fastening, at device: Screw type Material: Metal
5	53800132	BTF815M	Mounting bracket	Application: Mounting bracket for floor mounting Dimensions: 186 mm x 120 mm x 288 mm Scan level height: 150 mm Color: Yellow, RAL 1021 Type of fastening, at system: Through-hole mounting Type of fastening, at device: Screw type Material: Metal
A	53800133	BTF830M	Mounting bracket	Application: Mounting bracket for floor mounting Dimensions: 186 mm x 275 mm x 288 mm Scan level height: 300 mm Color: Yellow, RAL 1021 Type of fastening, at system: Through-hole mounting Type of fastening, at device: Screw type Material: Metal

Accessories



Mounting

	Part no.	Designation	Article	Description
P	53800131	BTP800M	Loop guard	Dimensions: 160 mm x 169 mm Color: Black Material: Metal

General

Part no.	Designation	Article	Description
430400	RS4-clean-Set1	Cleaning set	Number of cleaning cloths: 40 Piece(s) Content of cleaning fluid: 150 ml

Services

Part no.	Designation	Article	Description
S981051	CS40-I-141	Safety inspection "Safety laser scanners"	Details: Checking of a safety laser scanner application in accordance with current standards and guidelines. Inclusion of the device and machine data in a database, production of a test log per application. Conditions: It must be possible to stop the machine, support provided by customer's employees and access to the machine for Leuze employees must be ensured. Restrictions: Travel costs and accommodation expenses charged separately and according to expenditure.
S981047	CS40-S-141	Start-up support	Details: For safety devices including stopping time measurement and initial inspection. Conditions: Devices and connection cables are already mounted, price not including travel costs and, if applicable, accommodation expenses. Restrictions: Max. 3 h., no mechanical (mounting) and electrical (wiring) work performed, no changes (attachments, wiring, programming) to third-party components in the nearby environment.

Note



🔖 A list with all available accessories can be found on the Leuze website in the Download tab of the article detailed page.