

## **Technical data sheet Safety relay** Part no.: 547936

MSI-DT30B-02



We reserve the right to make technical changes eng • 2021-01-28

Leuze electronic GmbH + Co. KGinfo@leuze.com • www.leuze.comIn der Braike 1, 73277 OwenPhone: +49 7021 573-0 • Fax: +49 7021 573-199

()

## **Technical data**

# Leuze

Series	MSI-DT		
Functions			
Functions	Cross circuit monitoring		
	One- or two-channel operation		
	Start/restart interlock (RES), selectable		
	Time-delayed shutdown (STOP1)		
Restart	Automatic		
	Manual		
Characteristic parameters			
SIL	3, IEC 61508		
SILCL	3, IEC/EN 62061		
Performance Level (PL)	e, EN ISO 13849-1		
MTTF <sub>d</sub>	124 years, EN ISO 13849-1		
PFH <sub>D</sub>	1,8E-09 per hour		
Mission time T <sub>M</sub>	20 years, EN ISO 13849-1		
Category	4, EN ISO 13849		
STOP category	0, IEC/EN 60204-1		
B10 <sub>d</sub> at DC13 (inductive load)	400,000 number of cycles		
B10 <sub>d</sub> at AC15 (inductive load)	400,000 number of cycles		
Electrical data			
Protective circuit	Short circuit protected		
Connection			
Number of connections	1 Piece(s)		
Connection 1			
Function	Connection to device		
	Voltage supply		

Terminal

16 -pin

Spring-cage terminal

 $1 \times 0.2$  to 2.5 mm<sup>2</sup>, wire  $1 \times 0.2$  to 2.5 mm<sup>2</sup>, wire

#### Mechanical data

Dimension (W x H x L)	22.5 mm x 111 mm x 114.5 mm	
Housing material	Plastic	
Plastic housing	Unreinforced polyamide PA	
Net weight	231 g	
Housing color	Gray	
Type of fastening	Snap-on mounting	
Mechanical life time	100,000,000 actuation cycles	
On emotion and display		
Operation and display		
Type of display	LED	
Number of LEDs	3 Piece(s)	
Environmental data		
Ambient temperature, operation	-20 55 °C	
Ambient temperature, storage	-40 70 °C	
Certifications		
Degree of protection	IP 20 (terminals)	
	IP 40 (housing)	
Certifications	c UL US	
	TÜV Rheinland	
	TUV Rheinland	
	TUV Rheinland	
Classification	TUV Rheinland	
Classification Customs tariff number	TUV Rheinland 85371098	
Customs tariff number	85371098	
Customs tariff number eCl@ss 5.1.4	85371098 27371800	
Customs tariff number eCl@ss 5.1.4 eCl@ss 8.0	85371098 27371800 27371819	
Customs tariff number eCl@ss 5.1.4 eCl@ss 8.0 eCl@ss 9.0	85371098 27371800 27371819 27371819	
Customs tariff number eCl@ss 5.1.4 eCl@ss 8.0 eCl@ss 9.0 eCl@ss 10.0	85371098 27371800 27371819 27371819 27371819	
Customs tariff number eCl@ss 5.1.4 eCl@ss 8.0 eCl@ss 9.0 eCl@ss 10.0 eCl@ss 11.0	85371098 27371800 27371819 27371819 27371819 27371819 27371819	
Customs tariff number eCl@ss 5.1.4 eCl@ss 8.0 eCl@ss 9.0 eCl@ss 10.0 eCl@ss 11.0 ETIM 5.0	85371098 27371800 27371819 27371819 27371819 27371819 27371819 EC001449	

## **Electrical connection**

#### **Connection 1**

Type of connection

Cable properties Connection cross sections

Type of terminal

No. of pins

Voltage supply   Type of connection Terminal   Type of terminal Spring-cage terminal   No. of pins 16 -pin	Function	Connection to device
Type of terminal     Spring-cage terminal		Voltage supply
	Type of connection	Terminal
No. of pins 16 -pin	Type of terminal	Spring-cage terminal
	No. of pins	16 -pin

#### Pin Pin assignment

	A1		
1	+24V		
	S35		
2	Start circuit		
	S34		
3	Start circuit		
	A2		

### **Electrical connection**

Pin assignment

Pin

## Leuze

• •••	
4	GND
	S11
5	Sensor input 1
	S12
6	Sensor input 1
	S21
7	Sensor input 2
	S22
8	Sensor input 2
	13
9	1 release circuit, undelayed
	14
10	1 release circuit, undelayed
	23
11	2 release circuit, undelayed
	24
12	2 release circuit, undelayed
	37
13	Release circuit 1, delayed
	38
14	Release circuit 1, delayed
	47
15	Release circuit 2, delayed
	48
16	Release circuit 2, delayed

### **Operation and display**

Display LED 1	Display LED 2	Display LED 3	Meaning
Green, continuous light	Off	Off	Operational readiness
Green, continuous light	Green, continuous light	Green, continuous light	Device is active. Release circuits are closed.
Green, quickly flashing	Off	Off	Internal error - device defective. Replace the device!
Green, slowly flashing	Off	Off	External error - check the wiring and power supply! In event of manual reset: check the time sequence!
Green, slowly flashing	Green, slowly flashing	Off	Configuration error - repeat the configuration! If this cannot be performed: check the wiring and power supply!
Green, slowly flashing	Green, slowly flashing	Green, slowly flashing	Configuration necessary - positioner for delay time was readjusted. Configure again!