
en 02-2010/11 50113349


# Ultrasonic scanners with background suppression

# **Dimensioned drawing**





- Small ultrasonic scanner in M12 round housing in protection class IP 67
- Various opening angles and sound cone geometries
- Switching behavior largely independent of surface properties
- Precise switching point adjustment through teach-in via a cable



- Active surface
- Green indicator diode








## **Accessories:**

## (available separately)

- M12 connectors (KD ...)
- Ready-made cables (K-D ...)

# **Electrical connection**



# **Specifications**

Ultrasonic data Scanning range Adjustment range of the switching point Opening angle Sound frequency Repeatability

Temperature drift Hysteresis

**Timing** 

Switching frequency Response time Decay time Delay before start-up

**Electrical data** 

Operating voltage U<sub>B</sub> 1) Residual ripple Bias current

Switching output/function .../4NO... .../4NC... .../2NO...

Output current Load

Teach input Signal voltage high/low

**Indicators** 

Green LED Green LED slowly flashing Green LED quickly flashing

**Mechanical data** 

Housing Active surface Standard measurement object 2) Attachment

Weight Connection type

**Environmental data** 

Ambient temp. (operation/storage) Protective circuit 3) VDE safety class Protection class

Standards applied

Certifications

-10°C ... +60°C/-40°C ... +85°C

in through hole or thread M12x1

1, 2, 3 III **IP 67** 

IEC/EN 60947-5-2

HRTU 412/...-S...

10 ... 200mm

30 ... 200mm

narrow

380 kHz

50Hz

≤ 10ms ≤ 10ms

≤ 200 ms

 $\leq$  35 mA

≤ 200 mA

. ≥ (U<sub>B</sub>-2V)/≤ 2V

teaching error

plastic (PC)

15 x15mm

teach event active

brass nickel-plated

approx. 10g M12 connector, 4-pin

.../2NC...

≤ 10% of U<sub>B</sub>

HRTU 412/...

40 ... 400mm

60 ... 400 mm

standard

290kHz

20Hz

 $\leq 25\,ms$ 

≤ 25 ms

30 x30mm

12 ... 30VDC incl. taking into account the residual ripple

≤ 0.5mm (relative to the switching point) ≤ 0.18%/K (relative to the switching point)

typ. 4% (relative to the switching point)

pin 4: PNP transistor, make-contact (NO) pin 4: PNP transistor, break-contact (NC)

pin 4: NPN transistor, make-contact (NO)

pin 4: NPN transistor, break-contact (NC)

switching state (on = object detected)

 $C_{\text{max}} = 10 \text{ nF}, L_{\text{max}} = 20 \mu \text{H}$ pin 2: active high

**UL 508** 

Observe the safety regulations and installation instructions regarding power supply and wiring; for UL applications: only for use in "Class 2" circuits acc. to NEC

Aligned perpendicular to sensor reference axis

1=polarity reversal protection, 2=short circuit protection, 3=overload protection for all outputs

### Remarks

## Approved purpose:


This product may only be used by qualified personnel and must only be used for the approved purpose. This sensor is not a safety sensor and is not to be used for the protection of persons.

### **Tables**


1	10	200		
2	40		400	
1	HRTU	J 412/S	3	
2	HRTU	J 412/		

## **Diagrams**

HRTU 412/...-S...




### HRTU 412/...





# Ultrasonic scanners with background suppression

# Type key



# Order guide

The sensors listed here are preferred types; current information at www.leuze.com.

Opening angle of the ultrasonic cone	Designation	Part No.
	HRTU 412/4N0.2-S-S12	50113993
Narrow	HRTU 412/4NC.2-S-S12	50113995
Natiow	HRTU 412/2N0.2-S-S12	50113997
	HRTU 412/2NC.2-S-S12	50113999
	HRTU 412/4N0.2-S12	50113994
Standard	HRTU 412/4NC.2-S12	50113996
Statiuaru	HRTU 412/2N0.2-S12	50113998
	HRTU 412/2NC.2-S12	50114000

# Switching point adjustment via teach-in

	Teach-in input PIN 2
① Activate teach-in	U <sub>B</sub> for approx. 2s, LED flashes
Place the object at the desired switching position and conclude the teach event	Position object U <sub>B</sub> briefly ends the teach event; LED on  The teach event ends after 2s, the sensor detects the object at this
	position and the LED is on. If the object is removed, the LED must be switched off.

## **Teaching error**

If the object is located outside of the scanning range during the teach event, a teaching error occurs.

The LED flashes quickly and the switching output is reset to the factory setting (switching point at the max. scanning range).

# Resetting the sensor to factory setting

	Teach-in input PIN 2
Restoring the factory setting	U <sub>B</sub> for at least 6s, LED flashes quickly

# Locking the teach input

The sensor automatically locks the teach input after either 5 min. after power-on or 5 min. after the last teach event is ended. A new teach event is only possible after disconnecting the sensor from voltage.

If the <b>Teach-IN</b> input is not used
it must be connected to GND!

HRTU 412... - 02 2010/11